

MOVE-Targeted Move

Move to specific positions

Furthermore, you can use the function TARGETED MOVE, for discrete distances in defined velocities and spindle speed. So it is quite simple to carry out any kind of material cut with great accuracy and without a hitch.



Manual movement

Machine co-ordinates	
X	35.575
Y	7.275
Z	5.000

Workpiece co-ordinates	
X	25.575
Y	-2.725
Z	-5.000

New position	
X	+ 10.000 mm
Y	+ 8.500 mm
Z	+ 5.000 mm

Feedrate: + 0.00 mm/s
spindle speed: 8000 U/min

☒ Machine co-ordinates
☐ Workpiece co-ordinates
☐ relative distance

Start

☐ Spindle
☐ Cooling
☒ Reset to endless
endless

Move to... Stop
Save to... Exit

Function Specific Move