

SPECIAL FUNCTIONS-JOYSTICK CALIBRATION

To be able to move the machine with a joystick, **WinPC-NC** needs to know the type and value ranges of the joystick signals. The JOYSTICK CALIBRATION function does this almost automatically.

*Determination
joystick
parameters
menu*

Instructions for operating the joystick are displayed in a window. Please follow these instructions exactly. The procedure involves pressing both buttons and moving the lever to certain positions.

The joystick cannot be used before it has been calibrated.

